

Dispenser Installation Guide

Clinell Universal and Clinell Biodegradable Universal Wipes

Below are the instructions to install and maintain Clinell Universal and Clinell Biodegradable Universal Wipes Dispensers. Product code: **CWDAUS**

Installation based on material:

- **Plasterboard** – two 6 x 35/45 mm wall anchors with 19 mm flat washers at the mid point in the bracket where the key holes are provided. An additional two screws (3 x 25mm button head) are positioned at the top of the bracket for support if required.
- **Concrete/masonry** – two 6 mm plugs (the hole drilled for the plug is a 5.5mm) with 3 x 25mm button head screws at the at the mid point in the bracket where the key holes are provided.
- **Joinery** – four flat head screws (3 x 12mm, 3 x 15 mm or 3 x 25 mm)
- **Metal framing** – two self tapping screws plus washers as required (3 x 12 mm or 4 x 38 mm)
- **Glass** – Double sided tape (unless against IPC policy)
- **Wire** – two heavy duty cable ties
- **Trolleys** – two heavy duty cable ties

Installation process:

1. Position the dispensers as close as possible to the nominated location ensuring dispensers are clear from services.
2. The position may change to utilise installed fixings and/or to conceal damage from previous dispensers.
3. The fixings nominated are adequate to hold the dispenser and product. Changes to fixing may be required to suit the specified site requirements.

Clinell Universal Wipes Dispenser facts:

Dimensions:

- Length 275 mm
- Width 130 mm
- Height 172 mm
- Weight 300 grams

Material:

- Polypropylene plastic

Loading:

- Wipes are loaded from the top
- Keep at least 160 mm clear for loading
- Dispensers are designed to house CW200AUS and CW140PFAUS only
- Load not to exceed 2.5 kgs

Cleaning:

- Follow facility policy
- Clinell Universal Wipes can be used

Ordering

- Use the Dispenser Request Form to order dispensers
- Carton quantity – 20 dispensers.

Lids are available.



Distributed by



1300 778 924



info@constar.com.au



www.constar.com.au